

Montage der Tischbefestigung / Assembling of the desk clamp

Zur Montage legen Sie das JL-G25 auf den Lenkradkranz wie in Bild 1 zu sehen ist. Die Winkelschiene der Tischbefestigung wird an den Punkten "A" mit dem Lenkrad verschraubt. Der beigelegte Gummifuss "B" wird an die hintere Abstützung geschraubt. Wie in der Bedienungsanleitung für das Lenkrad beschrieben, lässt sich auch bei Benutzung der Tischbefestigung der Neigungswinkel des Lenkrades verstellen. Achtung, ziehen Sie die Schraubzwinge nur mit der Hand so fest wie nötig, benutzen Sie hierfür auf keinen Fall Werkzeuge wie z. B. eine Rohrzange.



To assemble the desk clamp, you best place the JL-G25 on the rim of the steering wheel like to be seen in photo 1. The angle bar of the clamp is tightened at the points "A" of the JL-G25. The enclosed rubber foot "B" has to be screwed to the rear support angle. Like already described in the manual of the JL-G25 the inclination angle of the wheel can be adjusted also, when using the desk clamp. Attention, please tighten the desk clamp by hand only as tight as just necessary. Never use any tools like e.g. pipe tongs to tighten the clamp.

